# **Compact Due**

# SODIUM-CALCIUM BENTONITE

In Compliance with International Codex Oenologique. Not derived from genetically modified organisms. Does not contain allergens.

# In fruit juices

COMPACT 2 is particularly indicated for the fining treatment of fruit juices.

The treatment with COMPACT 2 results in juices definitely more stable to cloudiness and haze phenomena.

One important peculiarity related to the fruit juice treatments is its relatively low contents in sodium compared to other bentonites.

The excellent quality of the raw materials chosen for COMPACT 2 preserve the treated product from acquiring anomalous odours or bad flavors.

# Fining of grape juices and wines

In the treatment of grape juices and wines, COMPACT 2 shows a good absorption capacity towards proteins and oxidizing enzymes. The flocculation resulting from its coagulation with other substances will cause the dragging and sedimentation of the colloidal materials present, which are the main cause of turbidity in grape juices and wines.

For these reasons COMPACT 2 can grant an excellent clearness but also a better colloidal stability to the treated products.

# Composition

Activated bentonite (E 558)

#### **Characteristics**

Appearance: powder. Color: gray-beige Average moisture: < 10% Calcination loss: 4,5-5,5% pH (2%): 9,0-10,0 Si0<sub>2</sub>: 71,5% Al<sub>2</sub>0<sub>3</sub>: 11,5% Fe<sub>2</sub>0<sub>3</sub>: 1,8% Ca0: 1,6% Mg0: 0,85% Na<sub>2</sub>0: 0,8% K<sub>2</sub>0: 1,6% Pb: < 6 ppm

#### Doses

Up to 2000 g/1000 liters in fruit juices 700-1500 g/1000 liters in grape juice, young wines and vinegars. 400-1000 g/1000 liters in rested wines.

## Instructions for use

Dissolve COMPACT 2 in cold water (ratio 1:10). Allow 8 to 12 hours for hydration, homogenize the solution and add it to the mass.

#### **Storage**

If it is kept dry and sealed in its original packing, the product preserves its original characteristics for several years

#### Notice

The addition of COMPACT 2 must follow a possible enzymes treatment by a period of time equal or longer than the contact time suggested for the enzyme treatment itself.

## Package

Code 112850 - 25 kg bag



#### Perdomini-IOC S.p.A.

Via Salvo D'Acquisto, 2 - 37036 S. Martino Buon Albergo (VR) Italy tel. +39-045-8788611 r.a. fax +39-045-8780322 fax uff. vendite +39-045-8780122 www.perdomini-ioc.com - info@perdomini-ioc.com



Le informazioni contenute in questa pubblicazione sono state verificate e ritenute corrette alla data di stampa.

Perdomini-IOC S.p.A. si riserva il diritto di modificare le caratteristiche senza preavviso.

Azienda con sistema di Gestione Qualità e Ambiente certificati secondo le Norme UNI EN ISO 9001 e UNI EN ISO 14001